Installation instructions TPW 1614

1) Remove Cover from J–box.
2) Shut off air and water supply valves.
3) Install Water Regulator Assembly 152003 into J–Box using 10–32 Screw and Square Nut provided.
4) Install Selector Valve 122330 into existing 1/2" hole. located in the bottom of the Console next to the Umbilical using Nuts provided. Ⓐ
5) Install City/Bottle Water Label on bottom of Console next to Selector Valve orientated as shown.
6) Remove blue tube from Water Bottle outlet and connect to position #1 on Selector Valve using Sleeve 117479 provided.
7) Connect 1/8 I.D. blue tube provided to the outlet of the Water Bottle using the Sleeve provided.
8) Cut tubing to proper length required to connect to position #4 of the Selector Valve using Sleeve provided
9) Remove 10–32 plug and washer from the water side of the Valve Block Assembly and replace with 10–32 x 1/8 Barb fitting and Washer provided.
10) Connect the remaining blue tube to the Barbed fitting on the valve block and cut to length required to connect to the inlet of the Water Regulator Assembly.
11) Connect remaining tubing to outlet of the Water Regulator Assembly using Sleeve provided.
12) Install tubing through umbilical tube and connect to position #2 on the Selector Valve with Sleeve provided
13) Turn on water and air shut–off valves and check for leaks.
14) Test Selector Valve by selecting city/bottle water. Note: City water regulator valve should be set to 40 PSIG. (Air regulator for bottle water is pre–set to 40 PSIG.)
15) Reinstall Cover on J–Box.

FLOW DIAGRAM